

HBM17158SS Compartmentalized Parts List

Location Number	Description	Part Number	Original Name	EXPLODED VIEW
REFRIGERATOR DOOR AND HINGES				
95	Refrigerator Left Upper Hinge Cover	K1428339	left upper hinge cover	
4	Refrigerator Right Upper Hinge Cover	K1416577	right upper hinge cover	
3	Upper Hinge/Adjustable Feet Self-Tapping S	K1099098	special flange self-tapping screw	
2	Refrigerator Right Upper Hinge	K1416576	upper hinge part	
97	Refrigerator Left Upper Hinge	K1428326	left upper hinge part	
76	Refrigerator Door	K1974099	refrigerator door	
1	Logo	K1501596	Logo	
74	Refrigerator Door Gasket	K1988800	gasket part (Refrigerator)	
77	Door Handle Reversing Plug (2)	K1981758	handle cover	
78	Door Handle Mounting Screw	K1540244	hinge supporter	
79	Refrigerator Door Handle	K4129515	upper hinge part	
101	Door Handle Set Screws	K1451785	ajustable bottom feet part	
69	Door Bin Cover	K4098723	shelf cover	
70	Small Door Shelves (4)	K1945509	small shelf	
72	Middle Door Shelf	K4098731	middle shelf	
73	Lower Door Shelf	K4098726	lower shelf	
96	Refrigerator Left Lower Hinge	K1976711	left middle hinge part	
6	Refrigerator Right Lower Hinge	K1976719	right middle hinge part	
7	Lower Hinge Machine Screw	K1534952	screw	

HBM17158SS Compartmentalized Parts List

Location Number	Description	Part Number	Original Name	EXPLODED VIEW
REFRIGERATOR CABINET				
10	Refrigerator Air Duct Foam	K1475629	refrigerator wind channel foam	
13	Refrigerator Air Duct Cover	K1482686	refrigerator air duct cover part-drawing	
14	Air Duct Self-Tapping Screw	K1104462	self-tapping screw	
15	Air Duct Screw Cover	K1118834	handle cover	
16	Self Tapping Screw	K1115532	self-tapping screw	
17	Display Board	K1980497	display board part	
18	LED Light PCB	K1627681	LED light	
19	Display/ Light Assembly	K4116936	Button display panel-drawing	
20	LED Light Cover	K1626540	light cover	
37	Door Switch	K1114246	door switch	
11	Electronic Damper	K1485764	electric wind gate	
12	Damper Housing Foam	K1475632	windchannel foam	
71	Return Air Duct Grill	K1468019	air return cover	

HBM17158SS Compartmentalized Parts List

Location Number	Description	Part Number	Original Name	EXPLODED VIEW
FREEZER DOOR				
84	Right Freezer Door Guide	K1557365	right drawer rail part	
67	Left Freezer Door Guide Rail	K1557363	left drawer rail part	
75	Freezer Door Gasket	K1988799	gasket part (Freezer)	
80	Freezer Door Handle	K4129516	lower hinge part	
101	Door Handle Set Screws	K1451785	adjustable bottom feet part	
78	Door Handle Mounting Screw	K1540244	hinge supporter	
68	Freezer Drawer Mounting Screws	K1099076	self-tapping screw	
36	Freezer Door Bracket Mounting Screw	K1115414	special flange self-tapping screw	
66	Freezer Magnet Cover	K1529145	fixed card of magnetic core	
65	Door Switch Magnet	K1467280	magnetic core	
86	Freezer Door	K1974289	freezer door	

HBM17158SS Compartmentalized Parts List

Location Number	Description	Part Number	Original Name	EXPLODED VIEW
FREEZER COMPARTMENT				
30	Fan Motor Nylon Grommet	K1461686	vibration pad	
28	Fan Motor Bracket	K1461700	fan motor supporter	
27	Self Tapping Screw	K1099042	self-tapping screw	
25	Fan Blade	K1111155	wind blade	
29	Fan Motor	K1952119	refrigerator fan	
30	Fan Motor Nylon Grommet	K1461686	vibration pad	
22	Freezer Evaporator Assembly	K1979907	freezer evaporator part	
21	Evaporator Self-Tapping Screw	K1104453	self-tapping screw	
89	Evaporator Assembly	K1475973	wing slice evaporator part	
90	Defrost Heater, Temp Sensor, Temp Fuse	K1973269	Defrost heater, Sensor, Temp Fuse	
88	Evaporator Pan Defrost Hook	K1434761	defrost stick	
33	Door Reed Switch	K1468523	Dry reed pipe (Door Sensor)	
32	Door Reed Switch Cover	K1467095	reed pipe cover	
23	Defrost Drain Pan	K1475669	water drain	
31	Freezer Air Duct Housing	K1475638	wind channel cover board in freezer cham	
26	Freezer Air Duct Foam	K1974248	Wind channelfoam in freezer chamber	
14	Air Duct Self-Tapping Screw	K1104462	self-tapping screw	
24	Freezer Air Duct Cover	K1974244	wind channel cover board in freezer chamber	

HBM17158SS Compartmentalized Parts List

Location Number	Description	Part Number	Original Name	EXPLODED VIEW
Shelves and Drawers				
53	Refrigerator 3 Upper Shelves	K1989358	shelf part	<p>The diagram shows an exploded view of various refrigerator components. At the top, three long, thin shelves are labeled 53. Below them, a dashed box contains a humidity control cover (62) and a crisper drawer cover housing (55). In the middle, a crisper drawer (54) is shown with its right guide rail (81) and left guide rail (56). Below the crisper drawer is a freezer top drawer/basket (58) with its right (82) and left (59) guide rails. At the bottom, a freezer bottom drawer basket (63) is shown with its right (83) and left (64) guide rails. Various screws (57, 27) and a locking rivet (60) are also shown.</p>
54	Crisper Drawer	K4098983	crisper drawer	
55	Crisper Drawer Cover Housing	K1572597	crisper box cover component	
62	Crisper Humidity Control Cover	K1490355	humidity conditioning slide block	
54	Crisper Drawer	K4098983	crisper drawer	
81	Right Guide Rail Crisper Drawer	K1475699	guided rail part for drawer	
56	Refrigerator Left Crisper Drawer Guide	K1475698	guided rail part for drawer	
57	Guide Rail Screws	K1099091	screw	
58	Freezer Top Drawer / Basket	K1945500	middle drawer part	
82	Right Guide Rail Upper Freezer Drawer	K1980225	right guided rail part for drawer	
59	Left Guide Rail Freezer Top Drawer	K1980223	left guided rail part for drawer	
27	Self Tapping Screw	K1099042	self-tapping screw	
63	Freezer Bottom Drawer Basket	K1979347	freezer lower drawer	
60	Freezer Gear Axle Locking Rivet	K1944366	bolt	
61	Freezer Gear Axle	K1978560	Rail link pole	
83	Right Guide Rail Lower Freezer Drawer	K1979570	right guided rail part for drawer	
64	Left Guide Rail Freezer Lower Drawer	K1979569	left guided rail part for drawer	

HBM17158SS Compartmentalized Parts List

Location Number	Description	Part Number	Original Name	EXPLODED VIEW
REAR AND BOTTOM COMPONENTS				
27	Self Tapping Screw	K1099042	self-tapping screw	
49	Main Control Board	K1623862	main control board	
51	Condenser Fixed Clip	K1522104	condenser fixed clip	
50	Defrost Evaporation Pan	K1562054	evaporating dish	
27	Self Tapping Screw	K1099042	self-tapping screw	
46	Filter Dryer	K1355795	dry filter	
48	Main Control Board Housing	K1618076	control board box	
47	Main Control Board Cover	K1618078	control board box cover	
44	Power Line Mounting Screw	K1099081	self-tapping screw	
45	Power Line Assembly	K1611314	power line	
34	Adjustable Leveling Feet	K2028148	ajustable bottom feet part	
99	Bottom Leveling Foot Mounting Bracket	K2023827	ajustable bottom feet part	
40	Bolts	K1492172	fastening components	
41	Compressor Grounding Wire	K1407418	compressor grounding wire	
35	Refrigerator Roller Axle	K1434052	roll wheel axis	
98	Refrigerator Rear Rolling Wheels	K1103815	roll wheel	
36	Freezer Door Bracket Mounting Screw	K1115414	special flange self-tapping screw	
43	Compressor Fill Tube	K1639201	process tube	
42	Compressor	K1980380	compressor part	
92	Starter Relay	K1512634	starter	
93	Compressor Overload Protector	K1563801	Compressor overload protector	
94	Compressor Capacitor	K1563802	compressor running capacitor	
37	Right Rubber Mount	K1111096	right impact board	
39	Left Rubber Mount	K1072839	impact board	
39	Left Rubber Mount	K1072839	impact board	
91	Connecting Tube	K1051128	connecting tube	
3	Upper Hinge/Adjustable Feet Self-Tapping S	K1099098	special flange self-tapping screw	

HBM17158SS Compartmentalized Parts List

Location Number	Description	Part Number	Original Name	EXPLODED VIEW
SEALED SYSTEM COMPONENTS				
22	Freezer Evaporator Assembly	K1979907	freezer evaporator part	
43	Compressor Fill Tube	K1639201	process tube	
91	Connecting Tube	K1051128	connecting tube	
42	Compressor	K1980380	compressor part	
38	Compressor Mounting Bolt	K1486161	screw	
92	Starter Relay	K1512634	starter	
39	Left Rubber Mount	K1072839	impact board	
93	Compressor Overload Protector	K1563801	Compressor overload protector	
37	Right Rubber Mount	K1111096	right impact board	
94	Compressor Capacitor	K1563802	compressor running capacitor	
21	Evaporator Self-Tapping Screw	K1104453	self-tapping screw	
89	Evaporator Assembly	K1475973	wing slice evaporator part	
90	Defrost Heater, Temp Sensor, Temp Fuse	K1973269	Defrost heater, Sensor, Temp Fuse	
88	Evaporator Pan Defrost Hook	K1434761	defrost stick	
46	Filter Dryer	K1355795	dry filter	
51	Condenser Fixed Clip	K1522104	condenser fixed clip	
50	Defrost Evaporation Pan	K1562054	evaporating dish	