




Location	Part ID	Revised Name	Original Name	Qty
	39	K1099043 self-tapping screw	self-tapping screw	9
	6	K1870520 Water Filter Inlet Cover	water supply inlet cover	1
	7	K1954245 Ice Maker Inlet Cover	cover part	1
	5	K1646501 Water Line Bracket	installation clip	5
	8	K2134072 Water Line Filter to Solenoid	Pipe	1
	9	K1950678 Water Line Supply to Filter	Pipe	1
	10	K2122807	Pipe	1
	11	K2122931	Pipe	1
	4	K2090429 Power Supply Board	power board	1
	2	K2037441 Control Board Cover Plate	control board box cover	1
	3	K2102666 Main Control Panel	main control panel part	1
	12	K2132822 Water Tank Inlet Cover	cover part	1
	1	K1099042 Self-Tapping Screw	tapping screw	11
	15	K2014376 Water Line Compression Connector Outle	Connector Nut	1
	37	K1936481 Power Cord	power line	1
	24	K1509873 Drain Line	drain connecting pipe	2
	34	K1492172 Board Screws and Washers	Screw and washer assembly	4
	14	K2014374 Water Line Nipple Connection	Tap Water Joint Connector	1
	13	K2016011 Water Line Compression Connector Supp	Pipe cover	1
	17	K2134224 Water Line Solenoid Valve Main	Dispenser Assembly	1
	39	K1099043 self-tapping screw	self-tapping screw	9
	38	K2005745 Compressor Compartment Cover Plate	compressor room back guard par	1
	32	K2084793 Compressor	compressor parts	1
	19	K1944146 Condenser	bottom condenser	1
	21	K1944645 Evaporation Drain Pan	evaporating dish	1
	150	K1355795 Filter Drier	dry filter	1
	36	K2097347 Inverter Board Assembly	inverter board part	1
	35	K1072839 Compress Mounting Bracket Left	Platen	1
	31	K1486161 Compressor Mounting Bolt	bolt	2
	25	K1959313 Condenser Fan Assembly	Fan Motor Parts	1
	22	K1543316 Compressor Base	compressor base part	1
	34	K1492172 Board Screws and Washers	Screw and washer assembly	4
	152	K1103815 Rear Roller	roll wheel	2
	33	K1936452 Electronic Refrigerant Valve	AC electromagnetic valve	1
	30	K1111096 Compressor Mounting Bracket Right	Right impact board	1
	1	K1099042 Self-Tapping Screw	tapping screw	11
	152	K1103815 Rear Roller	roll wheel	2
	23	K1115414 special flange self-tapping screw	special flange self-tapping screw	12




40	K2094749 R2 Right Refrigerator Door	R2-Room door	1
41	K1501955 Magnet	magnetic core	1
44	K2109505 R1 Left Refrigerator Door	R1-Room door	1
43	K2092524 Vertical Mullion Flap	vertical baffle part	1
41	K1501955 Magnet	magnetic core	1
49	K2138326 Display Screen Stencil	display decorative board part	1
48	K2092719 Display Board	functional board part	1
47	K2092729 Ice Dispenser Door Assembly	Dispenser Assembly	1
42	K1099082 Cross recessed pan head tapping screw	Cross recessed pan head tapping	20
46	K2092683 Ice Passage Bracket	Ice Guide	1
50	K2125517 Dispenser Lever	impact pole	1
51	K1956129 Dispenser Spring	spring	1
52	K1616509 Dispenser Switch	switch	1
53	K2135280 Left Door Upper Shelf	upper shelf	1
67	K4088543 Right Door Shelves	upper shelf	3
54	K2135283 Left Door Middle Shelf	middle shelf	2
61	K1879147 Rubber Bumper	vibration pad	4
66	K1929804 Right Door Closer	limit block	1
65	K2028894 Right Door Stop	door stopper	1
57	K1145004 Pan head screw with cross recess	Pan head screw with cross recess	2
58	K1880404 Freezer LED Light	LED light	1
59	K1875291 Freezer LED Cover	light cover	1
55	K1875503 Left Door Closer	left middle hinge part	1
56	K2092710 Left Door Stop	door stop	1
64	K1944448 Right Rail Door Bracket	Right rail bracket	1
61	K1879147 Rubber Bumper	vibration pad	4
60	K2094750 Freezer Door with Brackets	freezer door	1
62	K2103152 Freezer Gasket	gasket part	1
63	K1944447 Left Rail Door Bracket	Left rail bracket	1
61	K1879147 Rubber Bumper	vibration pad	4
23	K1115414 special flange self-tapping screw	special flange self-tapping screw	12




101	K1899929 Water Filter Upper Housing	filter fixed rack	1
100	K1104462 SELF-TAPPING SCREW	Cross recessed pan head tapping	3
103	K1878780 snap ring c-shim	snap ring	10
98	K1958593 Water Filter - Complete	filter part	1
97	K2025625 installation clip\B05162272\A02\ABS\BC	installation clip	1
102	K1958591 Water Filter Connection	filter holder	1
86	K1104453 Cross recessed pan head tapping screw	Cross recessed pan head tapping	32
96	K1911860 Water Filter Housing Lower	filter holder-drawing	1
99	K1899937 Water Filter Guide	water baffle	1
153	K1958594 Water Filter with Connection	filter components	1
104	K1944418 Refrigerator Left Shelf Mounting Bracket	fixed board	2
86	K1104453 Cross recessed pan head tapping screw	Cross recessed pan head tapping	32
105	K1944446 Cap for Shelf Bracket	bracket cover	2
100	K1104462 SELF-TAPPING SCREW	Cross recessed pan head tapping	3
106	K1944417 Refrigerator Right Shelf Mounting Bracket	fixed board	1
110	K1944584 Refrigerator Return Air Duct Grill	refrigerator air return cover	1
100	K1104462 SELF-TAPPING SCREW	Cross recessed pan head tapping	3
107	K1973736 Water Tank Valve	electric valve	1
108	K1944440 Water Tank Brackets	installation clip	2
109	K1955364 Water Tank	water storage box part	1
69	K4155204 Refrigerator Air Duct Assembly	wind channel part in refrigerator c	1
147	K1944413 Refrigerator Air Duct Foam	Refrigerated wind channel foam	1
72	K1485764 Electric Damper	electric damper	1
148	K1944416 Damper Foam Housing	Wind gate foam	1
70	K4155069 Refrigerator Air Duct Housing	refrigerator air duct cover part-dra	1
71	K1430814 Refrigerator Compartment Temp Sensor	temperature sensor unit	1
73	K1958295 Refrigerator Air Duct Sealant Tape	sponge block	1



86	K1104453 Cross recessed pan head tapping screw	Cross recessed pan head tapping	32
149	K1051790 Freezer Defrost Temp Sensor	temperature sensor unit	1
111	K2084776 Evaporator, Heater, Drain Assembly	wing slice evaporator component	1
74	K1944423 Freezer Air Duct Assembly	wind channel part in freezer charr	1
145	K1539491 Freezer Air Duct Damper Sealant Tape	sponge block	1
142	K1620938 Fan Motor Rear Mounting Plate	back fan motor cover	1
143	K1944428 Freezer Air Duct Rear Housing	wind channel cover board in freez	1
149	K1051790 Freezer Defrost Temp Sensor	temperature sensor unit	1
77	K1870599 Interior Fan Motor	refrigerator fan	1
141	K1620952 Fan Motor Bushing	back fan motor cover	1
76	K1602291 Fan Blade	wind blade	1
75	K1909101 Freezer Compartment Temp Sensor	temperature sensor unit	1
144	K1944429 Freezer Air Duct Front Housing	Wind channel board in freezer che	1
74	K1944423 Freezer Air Duct Assembly	wind channel part in freezer charr	1



78	K2136067 Refrigerator Left Upper Shelf	shelves assembly	1
79	K2136063 Refrigerator Right-Upper/Left-Middle Shel shelves assembly		2
80	K2136070 Refrigerator Right Middle Adjustable Shel	Folding shelf par	1
81	K2104900 Refrigerator Bottom Shelf Crisper Cover	crisper box cover part-drawing	1
82	K4088566 Crisper Drawer	crisper box part	2
84	K2104786 Crisper Drawer Guides	crisper box cover part	1
83	K1968675 Deli Tray Cover	front cover of multifunctional roo	1
88	K1944292 Right Deli Tray Guide Rail	right guided rail part for drawer	1
85	K1944294 Left Deli Tray Guide Rail	left guided rail part for drawer	1
86	K1104453 Cross recessed pan head tapping screw	Cross recessed pan head tapping	32
89	K2106042 Freezer Upper Drawer	upper drawer part	1
87	K4088568 Deli Tray	multifunctional drawer part	1
90	K1944361 Freezer Timing Axle	Rail link pole	1
91	K1944366 Locking Snap Rivet for Timing Axle	bolt	1
92	K1944344 Freezer Drawer Right Guide Rail	right guided rail part for drawer	1
93	K1944341 Freezer Drawer Left Guide Rail	left guided rail part for drawer	1
23	K1115414 special flange self-tapping screw	special flange self-tapping screw	12
94	K1944537 Freezer Drawer Switch Trigger	Fixed card of magnetic core	1
95	K1944268 Freezer Lower Drawer	lower drawer part	1



34	K1492172 Board Screws and Washers	Screw and washer assembly	4
122	K2034715 Left Upper Hinge	left upper hinge part	1
123	K1099098	special flange self-tapping screw	12
124	K2132835 Hinge Cover Plate	top cover plate part	1
39	K1099043 self-tapping screw	self-tapping screw	9
125	K1949918 Door Water Shut Off Switch	door switch	1
126	K1944735 Gasket	Reflective baffle	1
127	K2092760 Push Fit Fitting	pipe connector	1
128	K1468523 Reed Switch Door Sensor	reed switch	2
129	K2086306 Right Upper Hiinge	right upper hinge part	1
121	K2103282 Drain For Ice Maker Heater	water drain part	1
120	K2095864 Cover Plate for Ice Maker Connections	bracket box	1
42	K1099082 Cross recessed pan head tapping screw	Cross recessed pan head tapping	20
86	K1104453 Cross recessed pan head tapping screw	Cross recessed pan head tapping	32
119	K2092520 Ice Auger Motor Assembly	ice-crushed Compartment Assem	1
118	K2106832 Ice Maker	automatic ice-maker part	1
117	K2122895 Ice Maker Housing	ice room	1
116	K2092815 Ice Bin	ice box part	1
131	K2110364 Fridge Upper LED Light	LED light	1
132	K1895817 Fridge Upper Light Cover	light part	1
133	K2124005 Fridge Slide Light Cover	light part	2
134	K1629348 Fridge Side LED Light	LED light	2
135	K2111949 Left Middle Hlnge	left middle hinge part	1
136	K1534952	screw	4
138	K1113925	self-tapping screw	2
137	K2104357 Right Middle Hinge	right lower hinge part	1
138	K1113925	self-tapping screw	2
140	K1948756 Leveling Leg Assembly	ajustable bottom feet part	2
151	K1947013 Adjustable Foot	ajustable bottom feet part	2
123	K1099098	special flange self-tapping screw	12